

**CAUTION**

Keep the unit dry – water or other liquids may damage the electronic components inside.

NOTES

The gauge will shut off automatically. There are no user serviceable parts. Tyre pressure for your vehicle can be found on the driver side door jam or in the owner's manual.

HOW TO MEASURE TYRE PRESSURE

1. Ensure the vehicle is stationary prior to measuring tyre pressure
2. Press button to turn the **Smart Tyre Gauge** ON
3. Remove the Dust Cap off the tyre valve, make sure the valve is free of debris, then push the **Smart Tyre Gauge** onto the tyre valve, make sure a good seal is made between the nozzle and valve stem so that no hissing sound of escaping air can be heard.
4. The **Smart Tyre Gauge** will automatically display the current tyre pressure
5. The **Smart Tyre Gauge** will turn OFF

HOW TO SAVE TYRE PRESSURE READINGS

1. The **Smart Tyre Gauge** can save up to 4 tyre pressure readings
2. Simply press to record the tyre pressure reading
3. Press to select another position to record your reading

HOW TO TURN THE LED LIGHT ON/OFF

1. Turn the unit on via the button
2. Once the unit is on, simply press to turn the light ON/OFF

DEFLATING TYRES

1. Turn the unit ON via the button
2. Remove the dust cap from the tyre valve, and push the **Smart Tyre Gauge** onto the tyre valve
3. Press and hold the button located on the underside of the **Smart Tyre Gauge**, until your desired pressure is reached.

CHANGING THE BATTERIES

1. Remove the 3 screws on the underside of the **Smart Tyre Gauge** and place the cover aside
2. Remove the 2 x CR2032 Batteries, making note of which way they are installed
3. Install 2 x New CR2032 batteries
4. Reinstall the back cover & install the 3 screws

SPECIFICATIONS

- 3 Measurement modes (psi, bar, kg²)
- Measurement range: 5 to 100 psi
- Operating temperatures: -20°C to 50°C

- Powered by 2 X CR2032 button batteries (included)
- Auto turn OFF feature: Yes (30 Seconds)
- Product dimensions: 153 x 35 x 35mm
- Weight: 80g

Office Contact Details

Phone: 1300 657 528



Fax: 1300 556 005



Email: enquiries@kincrome.com.au



Website: www.kincrome.com.au

Caring For The Environment

When a tool is no longer usable it should not be disposed of with household waste, but in an environmentally friendly way. Please recycle where facilities exist. Check with your local council authority for recycling advice.



Recycling packaging reduces the need for landfill and raw materials. Reuse of recycled material decreases pollution in the environment. Please recycle packaging where facilities exist. Check with your local council authority for recycling advice.

K8310

Made to Kincrome Tools & Equipment Pty Ltd global specifications and quality standards in China

Australia & Global

www.kincrome.com.au

enquiries@kincrome.com.au

Warranty given by Kincrome Australia Pty Ltd of Lakeview Drive, Carribbean Park, Scoresby, Victoria, Australia (Tel +61 3 9730 7100) If this product has materials or workmanship defects (other than defects caused by abnormal or non warranted use) you can, at your cost, send the product to place of purchase, an authorised Kincrome service agent or one of Kincromes addresses for repair or replacement. Your rights under this warranty are in addition to any other rights you have under the Australian Consumer Law or other applicable laws. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. For further details please visit www.kincrome.com.au or call us. Due to minor changes in design or manufacture, the product you purchase may sometimes differ from the one shown on the packaging.